

When Image Experience Matters.



# LC15 SERIES QUICK START GUIDE

### LC15 Series

Thank you for choosing Planar's LC15 series touchscreen monitor.

#### Customer Service:

To view online documentation and frequently asked questions, or to send an email to our technical support staff, please visit: www.planar.com/support or call 1-866-PLANAR1 (1-866-752-6271).


To receive advanced notification of product updates, please register your monitor at www.planar.com/support.

Planar is one of the world's most accomplished providers of flat-panel displays, with over 27 years expertise in flat-panel innovation. The company provides the most dependable display solutions for various applications in industrial, medical, and commercial markets.


## Monitor Set-up

- If it is necessary, clean the front surface of the display by using clean, compressed air or by using only a clean, dry soft cloth.
- Mount the monitor to your enclosure using your hardware. Detailed mechanical drawings, including mounting hole patterns, may be found at: www.planar.com/support
- 3. Securely tighten all mounting hardware.
- 4. Connect the video and power cables.
- Power up the computer. See the user's guide for your product at: www.planar.com/support for advanced set-up instructions.

For best performance, set your computer video graphics resolution to 1024 x 768.



# Package Overview



The test results show that this device meets the FCC rules. Refer to the product operation manual for FCC classification found at www.planar.com/support. Those limits are set to protect residential areas from devices with harmful emission. This device will produce, use, and radiate radio frequency energy. Failure to follow the user's manual to install or use this device might produce harmful interference with radio communication. Planar does not guarantee that this type of harmful interference will not occur in some special installations. The interference caused by this device with the reception of radio or television signals may be verified by turning the device on and off. Any changes or modifications to this TFT LCD would void the user's authority to operate this device.

020-1134-00